



SP-14S

Blade Installation Guide

***FOR USE WITH 2315 DATE CODE AND NEWER**

- Step 1: Loosen set screw, accessible from the top of the prep tool body as shown.
- Step 2 :Remove blades from pockets and clear any debris that may reside in the prep tool body.
- Step 3: Place new blades following the location guide below and tighten.
- Step 4: Replace set screw and tighten to insure left cutter blade is properly seated in the prep tool body.

